

Table of Contents

Temperature Monitoring using an USB Sensor 3

Detection by your System 3

Compiling Software to read temperature data 3

Munin Plugin 4

Links 5

Temperature Monitoring using an USB Sensor

- and statistical detection with munin

Productname	Hid TEMPerNTC
Link Producer	PCSensor
Amazon Link	hear (german)

Detection by your System

- dmesg when you insert the sensor, you have to check VendorID and ProductID "0C45:7401" because the given C program is only for this.

```
Jul 17 13:26:37 thor kernel: [1454078.048583] input: RDing TEMPer2V1.0 as
/devices/pci0000:00/0000:00:1d.0/usb2/2-2/2-2:1.0/input/input20
Jul 17 13:26:37 thor kernel: [1454078.048860] generic-usb
0003:0C45:7401.0007: input,hidraw0: USB HID v1.10 Keyboard [RDing
TEMPer2V1.0] on usb-0000:00:1d.0-2/input0
Jul 17 13:26:37 thor kernel: [1454078.063670] generic-usb
0003:0C45:7401.0008: hiddev96,hidraw1: USB HID v1.10 Device [RDing
TEMPer2V1.0] on usb-0000:00:1d.0-2/input1
```

Compiling Software to read temperature data

- Perhaps you will need some additional packages when you are using Ubuntu. For Arch no additional packages were needed when I tested it.

```
apt-get install libusb-dev libhid-dev libusb-1.0-0
```

```
wget http://www.isp-sl.com/pcsensor-0.0.1.tgz
tar xvzf pcsensor-0.0.1.tgz
cd pcsensor-0.0.1
rm pcsensor
make
./pcsensor
#2011/07/17 13:26:42 Temperature 72.61F 22.56C
cp pcsensor /usr/local/bin/
pcsensor
2011/07/17 13:34:42 Temperature 72.61F 22.56C
```

Munin Plugin

- Here a plugin for Munin for temperature monitoring
- Information about Munin you will find [here](#)

[hid-temper-ntc](#)

```
#!/bin/sh
#
# Plugin to monitor Temperature with HidTEMPerNTC from pcsensors
# 2011/07/17 EanderAlx
#
# ln -s /usr/share/munin/plugins/hid-temper-ntc /etc/munin/plugins/hid-temper-ntc
#
# Magic markers (optional - only used by munin-config and some
# installation scripts):
#%# family=contrib

if [ "$1" = "config" ]; then
    MODEL="Hid TEMPerNTC"
    LOCATION="Hid TEMPerNTC PC Sensor"
    NAME1="Hid TEMPerNTC USB Temp Sensor"
    echo "graph_title $LOCATION - Temperatur"
    echo "graph_args --base 1000"
    echo "graph_vlabel Celsius"
    echo "graph_category sensors"
    echo "graph_info This graph shows Temperatur data from
$LOCATION"
    echo "templ.label $NAME1"
    echo "templ.type GAUGE"
    echo "templ.info Celsius."
    echo "templ.colour 00ff00"
    echo "templ.max 50"
    echo "templ.min -10"
    exit 0
fi
WERT1=`/usr/local/bin/pcsensor | awk '{print $NF}' | cut -d "C" -f1`
echo -ne "templ.value $WERT1"
```

```
/etc/init.d/munin-node restart
telnet 127.0.0.1 4949
list
... hid-temper-ntc ...
```

Links

- <http://relavak.wordpress.com/2009/10/17/temper-temperature-sensor-linux-driver/>
- http://www.pcsensor.com/index.php?_a=viewProd&productId=32

From:

<https://www.eandalx.org/> - **EanderAlx.org**

Permanent link:

https://www.eandalx.org/linux/hid_temper_pc_sensor

Last update: **23.03.2013 18:45**

